

WARNING! Buyer/user assumes all responsibility for safety and proper use not in accordance with the directions and safety labels



## WAVE POINT COLOR TRANSFORMER LED FISH BOWL BASES & KITS



## PARTS & DIMENSION



## AVAILABLE MODEL

Item No.	Description	UPC No.
01232	Small fish bowl (1/2 gallon/1.9 liter)	805552012323
01233	Large fish bowl (1 gallon/3.7 liter)	805552012330
01234	Small color transformer LED fish bowl base	805552012347
01235	Large color transformer LED fish bowl base	805552012354
01236	Small color transformer LED fish bowl kit (1/2 gallon/1.9 liter)	805552012361
01237	Large color transformer LED fish bowl kit (1 gallon/3.7 liter)	805552012378

## FISH BOWL CAPABILITY LIST

### Fish Bowl for Small LED Fish Bowl Base

Description	UPC No.
Wave Point small fish bowl (1/2 gallon/1.9 liter)	805552012323
Anchor Hocking 1/2 gallon footed bowl	076440232622
1/2 gallon Round Fish bowl	737257187122
Koller Craft 1 gallon Plastic fish bowl	737257260917
1 gallon deluxe plastic round betta bowl	800443166161

### Fish Bowl for Large LED Fish Bowl Base

Description	UPC No.
Wave Point large fish bowl (1 gallon/3.7 liter)	805552012330
Anchor Hocking 1 gallon footed bowl	076440251784

**NOTE: This is a guideline, there may be other bowls in the market that fit Wave Point LED bases. If using other bowls not listed, the bowl must be placed so that the bowl is resting on the brim of the base.**

## IMPORTANT WARNING AND SAFEGUARDS

- READ AND FOLLOW THE GUIDELINES TO ENSURE THE PROPER USE AND APPLICATION. FAILURE TO FOLLOW THESE GUIDELINES MAY RESULT IN LED BASE DAMAGE, ELECTRICAL SHOCK, FIRE AND/OR INJURY.
- WARNING! HANDLE WITH CARE.
- BEFORE WORKING ON THE LED BASE AND/OR BOWL, THE LED BASE MUST BE DISCONNECTED FROM THE POWER SUPPLY.

This product may contain chemicals known to the state of California to cause cancer and or birth defects or other reproductive harm. Wash your hand after handling this product.


It is your sole responsibility to verify that the plug and the receptacle are clean and free of moisture and salt build up at all times. The receptacle must be free of water, salt, calcium, magnesium and dust. Failure to do so can cause fire, damage to property, permanent damage to the product and personal injury not limited to loss of life.

Do not plug into extension cord or power strip.

Hg lamp contains Mercury. Manage in accordance with disposal laws. See: [www.lamprecycle.org](http://www.lamprecycle.org)

A drip loop must be used when plugging all electrical aquarium devices. A drip loop is that part of the cord hanging below the receptacle.

The national code requires that a GFCI (Ground fault circuit interrupter) be used in the branch circuit supplying all power to water pumps and electrical aquarium equipment. If you do not have a GFCI, have an electrician install one prior to operating any aquarium component.



3

## ADDITIONAL SAFETY PRECAUTIONS & WARNINGS:

**Age Recommendation: 13 years or over. Not a toy. Not intended for use by children without direct adult supervision. As the user of this product, you are solely responsible for operating it in a manner that does not endanger yourself and others or result in damage to the product or the property of others.**

Read and follow the guidelines to ensure the proper use and application. Failure to follow these guidelines may result in base damage, electrical shock, fire and/or injury.

- The national code requires all aquarium equipment to be plugged into a GFCI (Ground Fault Circuit Interrupter) electrical outlet. The code requires that a GFCI be used in the branch circuit supplying all water pumps and electrical aquarium equipment.
- Do not plug into a power strip or extension cord.
- For indoor use only.
- Use the product for its intended use only.
- Never yank or pull on the cord from the electrical outlet.
- Do not operate the light if the plug and or wire is damaged.
- The LED base must be turned off/disconnected from the power supply before any maintenance is done to either the LED base or the bowl.
- Verify that hands are dry prior to disconnecting power.
- If the LED base falls or comes in contact with water/excess moisture, unplug the LED base from the power supply immediately before removing. Failure to do so may cause electrical arcing resulting in possible fire or electrical shock.
- Note: Any water damage to the LED base voids all warranties

4

## INSTRUCTION

**Warning! Do not lift fish bowl and LED base at the same time!**  
**Important: For full effect use only transparent glass/acrylic gravel**

**CAUTION! NOT a Toy. Glass bowl. Handle with care. Do not lift the bowl with wet hands. Never pick the bowl up from the brim! Always use two hands when handling**



1. Place in desired location
2. Place the bowl in the base
3. Verify that the bowls edge is resting on the brim of the base & is stable
4. Rinse gravel & place in the bowl (note: gravel is not included)
5. Add room temperature water & proper water conditioner/de-chlorinator
6. Verify the bowl is stable in the base
7. Connect the cable to the transformer
8. Plug directly to a GFCI outlet



5

## TROUBLESHOOTING

FOR QUESTIONS AND ANSWERS, VISIT OUR WEBSITE  
[www.wave-point.com](http://www.wave-point.com)

## WARRANTY

<http://www.wave-point.com/warranty.html>

### 30 DAY PRODUCT GUARANTEE

- If within 15 days of purchase you experience any problems with this Wave Point® Technology product, return it to the retailer where purchased for replacement. Product must be returned in its original box, with all original parts and must be accompanied by the original receipt as proof of purchase.
- Products beyond the 30 days of purchase that experience problems should NOT be returned to the retailer, supplier, or distributor. These Wave Point® products fall under the auspices of the Wave Point® Technology 1 year limited direct manufacturer warranty. All such problems must be addressed directly with Wave Point® by the warranty holder (see below).

### 1 YEAR DIRECT MANUFACTURER LIMITED WARRANTY

Wave Point® Technology products are warranted to all registered warranty product owners to be free of defect in materials and workmanship for one (1) year from date of purchase.

6

### RETURNING PRODUCTS FOR WARRANTY REPAIR

Contact Wave Point® Customer Support at [www.wave-point.com/helpdesk.html](http://www.wave-point.com/helpdesk.html) for all trouble shooting, warranty verification and return authorization numbers.

#### NOTE:

**Products returned without Return Authorization Numbers will be refused.**

#### Procedures:

##### **I HAVE A COPY OF MY ORIGINAL COMPLETED WARRANTY CARD:**

Wave point® product owners seeking warranty resolution should return their Wave Point® product directly to the manufacturer along with:

1. Return Authorization Number clearly written on outside of box.
2. Copy of warranty card with attached copy of original receipt as proof of purchase.
3. Warranty holder's address, phone number & email address if different than listed on warranty card.
4. Written explanation of problem.

##### **I DO NOT HAVE A COPY OF MY ORIGINAL COMPLETED WARRANTY CARD:**

In the event you do NOT have a copy of your original completed Warranty Card you may choose instead to forward your full customer contact information and proof of purchase as listed below:

1. Return Authorization Number clearly written on outside of box.
2. Copy of original receipt as proof of purchase.
3. Warranty holder's name, address, phone number and email address.
4. The Wave Point® serial number as listed on the product being returned.
5. Written explanation of the problem.

#### SEND TO:

Wave Point® Technology/Warranty Repair Desk  
300 South Lewis Rd. Unit J, Camarillo, CA 93012. USA

8

- URGENT: Fill out the warranty registration card included in this box to activate registration in the Wave Point® limited warranty program. Warranty card must be completed and returned to Wave Point® Technology within thirty (30) days of purchase (Warranty Card ).
- Under this program, Wave Point® Technology will, at its election, repair, replace or make appropriate adjustment where inspection by the Wave Point® company discloses any such defects occurring in normal usage within one (1) year after consumer purchase.
- Only properly registered Wave Point® products are eligible for this warranty service.
- After the 15 (fifteen) day guarantee has expired, contact Wave Point® Technology directly for warranty product repair. Do NOT return such Wave Point® products to the retailer, distributor or supplier for repair or replacement.
- Wave Point® Technology is not responsible for any removal, installation or shipping costs incurred in the warranty process.
- Warranty is void if the failure of Wave Point® product or system or any part, sealant or component thereof is found to be caused by misuse, tampering, negligence, abuse, misapplication, failure to properly maintain the product, failure to keep dry (not to come in contact with water), salt build up, or use without Ground Fault Circuit Interrupter.
- This warranty is non-transferable.
- This warranty is limited to possible parts replacement and labor connected there with. Wave Point® Technology is not liable for any incidental or consequential damages including but not limited to loss of life, personal injury, property damage, damage to equipment, or lost wages, income, profits or savings.
- Note: Some US states do not allow liability limitations or exclusions on incidental or consequential damages to the extent listed in the above disclaimer. Check your local state regulations for details on regulations specific to your state.

**NOTE: Wave Point® Technology's warranty policy is subject to change without notice.**

7

In the event Wave Point® products are returned for warranty work and are found to be outside the parameters of the warranty or otherwise caused by other than normal usage, the warranty holder will be contacted by phone or email and offered the option of (a) repair and return at the owner's expense, (b) return of the product to the owner "as is" at the owner's expense, or (c) disposal of the product. Only prepaid freight returns will be accepted. All freight is the responsibility of the warranty holder.

**NOTE: Wave Point® Technology's warranty policy is subject to change without notice.**

### RETURNING PRODUCTS FOR OUT-OF-WARRANTY REPAIR

Wave Point® owners experiencing problems with a Wave Point® product no longer under warranty may send their Wave Point® product to Wave Point® Technology for repair.

For help with, or repair of, products no longer under warranty, for trouble shooting tips and/or return authorization numbers, contact Wave Point® Customer Support at [www.wave-point.com/helpdesk.html](http://www.wave-point.com/helpdesk.html). Products returned without a return authorization number will be refused.

#### Procedures:

Wave Point® product owners seeking product repair should return their Wave Point® product directly to the manufacturer along with:

1. Return Authorization Number clearly written on outside of box.
2. Owner's name, address, phone number and email address.
3. The Wave Point® serial number as listed on the product being returned
4. Written explanation of problem.

#### SEND TO:

Wave Point® Technology/ Repair Desk  
300 South Lewis Rd. Unit J, Camarillo, CA 93012

9

## 1 YEAR LIMITED WARRANTY OWNER REGISTRATION CARD

### Wave Point LED Fish Bowl Bases & Kits

Wave Point® product owners MUST register their purchase with Wave Point® Technology for their warranty benefits to be in effect. Unregistered products are not eligible for warranty. This warranty card must be completed and submitted within 30 days of product purchase. Send this completed form along with a copy of the original retail receipt as proof of purchase to:

Wave Point® Technology/Warranty Submissions Desk  
300 South Lewis Rd. Unit J, Camarillo, CA 93012

#### OWNER INFORMATION

Date

Name:

Address:

City:

State/Province:

Postal Code:

Country

Email:

Cell Phone:

Work Phone:

Home Phone:

#### PRODUCT INFORMATION

Model No.

Date of Purchase:

Seller (Retail Outlet):

Seller's Location:

Seller's Phone:

\*Affix a copy of your original purchase receipt here  
**IMPORTANT: Please make a copy of this warranty card and retain it for your records.**



All repair and shipping costs are the responsibility of the owner. Depending on the problem and/or cost, products are not always repairable. In such instances all shipping costs remain the responsibility of the owner. If a Wave Point® product returned for repair is found to be either non-repairable or beyond a reasonable cost to repair, the owner will be contacted by Wave Point® and offered the option of either disposal of the product or return to the owner at the owner's expense.



Wave Point® Technology  
[www.wave-point.com](http://www.wave-point.com)

©2013 Wave Point® Technology  
Photo: ©Wave Point®  
All rights reserved

SPECIFICATIONS ARE SUBJECT TO CHANGE WITHOUT NOTICE

10